



BroadWeb Corporation 

The text 'BroadWeb Corporation' is in a bold, blue, sans-serif font. To its right is a stylized spider logo with a red body and blue legs.

Broadweb Products Registration Guide



First of all, Broadweb would like to thank you for choosing to use our NetKeeper products. In order for Broadweb to continuously provide better warranty & service to our loyalty customers, Broadweb will launch our all new product registration system on 1.1.2005. This will require user to register their product with our system for accessing our latest update after you have finished this registration procedure. It allows user to connect with our Data Update Centre (DUC) to have the following services:

- 7x24 Signature Pattern Update
- 7x24 System Kernel Update
- 7x24 System plug-in function update
- Customer service system will monitor device status and reply user's requirements.

For protecting their warranty right on this product, User is required to register their product on our Broadweb web site <<http://www.broadweb.com/>>. BEMS Server will auto update the latest signature pattern 、 kernel and enhance system function 、 after this product registration procedure ◦

Please follow the following steps to register your products:

1. Connect to Broadweb website [Http://www.broadweb.com/](http://www.broadweb.com/) and click Product Registration link to start register your product ◦
2. First, please fill up the registration form to become our broadweb register user and meanwhile a confirmation letter will send to your email account after this registration. Please click on the confirmation link within this email to activate your user account ◦
3. Next, login to the product registration website again and enter your username and password for accessing your own product website ◦

There will be no available registered product on this product term at your own product website unless you finish your product registration, Broadweb



serviceman will update user product detail into their respective product website within seven days after the product registration.

4. Click and download BEMS A/K ([Activation Key](#)) ◦
-

Since all BEMS Server will stop functioning on 12.31.2004 with the current BEMS A/K. You must replace this BEMS A/K (Activation Key) without effect your user right.

When you downloaded this BEMS A/K, our registration system will send the same information to your register email account.

5. Please stop your BEMS service.
-

Stop BEMS service in windows system

Start>>control panels>>Administrative tools>>service>>click BEMS and stop service.

Stop BEMS application

Click BEMS application window>>type CTRL+C>>system will inquiry whether user would like to stop >>type yes

6. Open the file BEMS_HOME/conf/system.license with a text editor
7. Copy and paste the key (example: A/K = YdzIOcgQQFXx4Kmr6BV5dg==) on a new line of the license file and then save the change.

```
# BEMS License Bundle
# Sealed at Wed Dec 01 10:00:59 GMT+08:00 2004
#
# License: system
# Expiration: Thu Mar 31 20:00:00 GMT+08:00 2005
system = MHN/+boiSPwPeN7zNtUMBtIvQVoZFyBFZTRwIW7060k64eCkGYSunq0uA470N7B1
A/K = YdzIOcgQQFXx4Kmr6BV5dg==
```

8. Restart the BEMS server. After you have completed this registration procedure, your BEMS server will automatically update signature pattern, kernel and enhance your system function with our DUC. You can browser your products on you own product website.



BroadWeb

www.broadweb.com

My Products

Welcome! **chen hilary**

You have registered **1** items.

[> Download BEMS Installer](#)

[> Request BEMS AK](#)

Product Registration

* Alias	Type	Model	S/N	Registration Date	Expiration Date	Status	Action
NetKeeper	NetKeeper	NK-3002T	NK300204080002	2004-10-21	2005-10-22	OK	Modify

Items marked by (*) are able to Modify

Registration Date : The date which the authorization user activate system update function

Expiration Date : The last valid day for allowing the authorization user to update their function

9. About BEMS Server operation detail please refer NetKeeper User Guide.